

## Test Patch Coverage Rate Chart

- To use: 1. Mark a 4, 6, or 8 sq. ft. area of the surface to be treated.  
2. Fill a graduated spray bottle with a set number of ounces of Professional Water Sealant.  
3. Apply top-down at a flow rate sufficient to create a 4 to 6 inch run down of product.  
4. Using chart, determine sq. ft. coverage based on ounces used & total sq. ft. of test area.

